

Smart
connections.

Operating manual

INVEOR P Drive Controller

Legal notice

KOSTAL Industrie Elektrik GmbH
An der Bellmerlei 10
58513 Lüdenscheid
Germany
Tel. +49 (0)2351 16-0
Fax + 49 (0)2351 16-2400
info-industrie@kostal.com

Exclusion of liability

All names, trademarks, product names or other designations given in this manual may be legally protected even if this is not labelled as such (e.g. as a trademark). KOSTAL assumes no liability for their free usage.

The illustrations and texts have been compiled with great care. However, the possibility of errors cannot be ruled out. The compilation is made without any guarantee.

General note on gender equality

KOSTAL is aware of how language impacts on gender equality and always makes an effort to reflect this in documentation. Nevertheless, for the sake of readability we are unable to use non-gender-specific terms throughout and use the masculine form instead.

© 2023 KOSTAL Industrie Elektrik GmbH

All rights reserved by KOSTAL, including those of reproduction by photocopy and storage in electronic media. Commercial use or distribution of the texts, displayed models, diagrams and photographs appearing in this product is not permitted. This manual may not be reproduced, stored, transmitted or translated in any form or by means of any medium - in whole or in part - without prior written permission.

1.	General information	6
1.1	Information about documentation	7
1.1.1	Other applicable documents.....	8
1.1.2	Storing the documentation	8
1.2	Notes in this manual	9
1.2.1	Warnings.....	9
1.2.2	Warning symbols used	9
1.2.3	Signal words.....	10
1.2.4	Information notes	10
1.3	Symbols used in this manual	11
1.4	Labels on the drive controller	12
1.5	Qualified staff.....	13
1.6	Proper use	13
1.7	Responsibility.....	14
1.8	EU Declaration of Conformity.....	15
1.9	Project planning information for housing design	16
1.9.1	Project planning information for housing design for STO variant	21
1.10	Safety instructions	23
1.10.1	General information	23
1.10.2	Transport & storage.....	25
1.10.3	Long -term storage	25
1.10.4	Information about commissioning	26
1.10.5	Instructions concerning operation	27
1.10.6	Maintenance and inspection	29
1.10.7	Repairs	29
2.	Overview of the drive controller	30
2.1	Model description size Alpha, size A - D	31
2.2	Scope of delivery	32
2.2.1	Scope of delivery for INVEOR P size Alpha.....	32
2.2.2	Scope of delivery for INVEOR P size A - D	33
2.3	Description of INVEOR P drive controller.....	34
3.	Installation.....	35
3.1	Safety instructions for installation	36
3.2	Recommended preliminary fuses / line protection	37
3.3	Installation requirements for INVEOR P size Alpha.....	38
3.3.1	Suitable ambient conditions (see chapter 1.9).....	38
3.3.2	Basic connection versions/power connections (INVEOR P size Alpha)	39
3.3.3	Basic connection versions/power connections (INVEOR P size A 1 IV02 [1 x 230 V AC]).....	41
3.3.4	Basic connection versions/power connections (INVEOR P size A IV01 [3 x 400 V AC]) ..	43
3.3.5	Basic connection versions (INVEOR P size B IV01 [3 x 400 V AC])	45
3.3.6	Basic connection versions (INVEOR P size C IV01 [3 x 400 V AC]).....	47
3.3.7	Basic connection versions (INVEOR P size D IV01 [3 x 400 V AC]).....	49
3.3.8	Short circuit and ground protection	51
3.3.9	Requirements of the brake resistors to use	51

3.4	Wiring instructions	52
3.4.1	Wiring instructions for control terminals INVEOR P size Alpha	52
3.4.2	Wiring instructions for control terminals INVEOR P size A-D	53
3.4.3	Preventing electromagnetic interferences	54
3.5	Installing the INVEOR P	55
3.5.1	Mechanical installation	55
3.5.2	Wiring diagram for INVEOR P size Alpha	56
3.5.3	Electrical installation for INVEOR P size Alpha	57
3.5.4	Electrical installation for INVEOR P size A-B	61
3.5.5	Electrical installation for INVEOR P size C-D	64
3.5.6	Connection diagram for INVEOR P size A-D	67
4.	Commissioning	73
4.1	Commissioning of INVEOR P size Alpha	73
4.2	Commissioning INVEOR P size A-D	73
5.	Parameter	74
5.1	Parameters for INVEOR P size Alpha	74
5.2	Parameters for INVEOR P size A-D	74
6.	Error detection and troubleshooting	75
6.1	Error detection and troubleshooting for INVEOR P size Alpha	75
6.2	Error detection and troubleshooting for INVEOR P size A-D	75
7.	Disassembly and disposal	76
7.1	Drive controller disassembly	76
7.2	Information on correct disposal	76
8.	Technical data	77
8.1	General data	78
8.1.1	General technical data for 230 V/400 V devices	78
9.	Optional accessories	81
9.1	MMI handheld controller including a 3 m RJ9 connection cable with M12 plug	83
9.2	MMI*/connecting cable PIN assignment	84
9.3	PC communication cable USB on M12/RS485 plug (converter integrated)	85
9.4	Adapter cable for INVEOR P size Alpha	86
9.5	Internal potentiometer	86
9.6	MMI M12 plug (JST plug)	87
9.7	CANopen connection cable	88
9.8	PROFIBUS connection cable	89
9.9	Ethercat/PROFINET/Sercos III connection cable	90
9.10	Thermal conductivity paste	91

10. Approvals, standards and guidelines 92

10.1 EMC limit classes 93

10.2 Classification acc. to IEC/EN 61800-3 94

10.3 Standards and guidelines 94

10.4 UL approval 95

10.4.1 UL Specification (English version) 95

10.4.2 Homologation CL (Version en française) 98

Mentions obligatoires 100

11. Index 103

1. General information

1.1	Information about documentation	7
1.1.1	Other applicable documents.....	8
1.1.2	Storing the documentation	8
1.2	Notes in this manual	9
1.2.1	Warnings.....	9
1.2.2	Warning symbols used	9
1.2.3	Signal words.....	10
1.2.4	Information notes	10
1.3	Symbols used in this manual	11
1.4	Labels on the drive controller	12
1.5	Qualified staff.....	13
1.6	Proper use	13
1.7	Responsibility.....	14
1.8	EU Declaration of Conformity.....	15
1.9	Project planning information for housing design	16
1.10	Safety instructions	23
1.10.1	General information	23
1.10.2	Transport & storage.....	25
1.10.3	Information about commissioning	26
1.10.4	Instructions concerning operation	27
1.10.5	Maintenance and inspection	29
1.10.6	Repairs	29

Thank you for choosing an INVEOR P drive controller (Cold Plate) from KOSTAL Industrie Elektrik GmbH! Our INVEOR line of drive controllers is designed to be universally usable with all common motor types.

If you have any technical questions, please call our central service hotline:

Tel.: +49 (0)2331 80 40-848

Monday to Friday: 7 am to 5 pm (UTC/GMT +1)

Fax: +49 (0)2331 80 40-602

E-mail: INVEOR-service@kostal.com

Website

www.kostal-industrie-elektrik.com

1.1 Information about documentation

The following information explains how to navigate through the documentation.

Read this manual carefully in its entirety. It contains important information for operating the INVEOR P.

We assume no liability for any damage resulting from non-observance of this manual.

This manual is an integral part of the product and applies exclusively to the INVEOR P from KOSTAL Industrie Elektrik GmbH.

Provide the operator of the system with this manual so it is available when needed.

1.1.1 Other applicable documents

This refers to all manuals that describe how to operate the drive controller system and any other manuals for the equipment used. Download the 3D files (.stp) for INVEOR P from <https://www.kostal-industrie-elektrik.com/downloads>.

A description of parameters is available for download (<https://www.kostal-industrie-elektrik.com/downloads>) for parametrising the drive controller system. In the download, you will find all the information required for correct parameterisation.

1.1.2 Storing the documentation

Store this operating manual and all other applicable documents carefully so they are available when needed.

1.2 Notes in this manual

1.2.1 Warnings




Fig.: 1 Structure of the warnings

- 1** Warning symbol
- 2** Signal word
- 3** Type of danger and its source
- 4** Possible consequence(s) of failure to comply
- 5** Corrective actions

1.2.2 Warning symbols used

Symbol	Meaning
	Danger
	Danger due to electrical shock and discharge
	Danger due to burns
	Danger due to electromagnetic fields

1.2.3 Signal words

Signal words are used to identify the severity of the danger.

DANGER

Indicates a direct hazard with a high level of risk, which, if not avoided, will result in death or serious injury.

WARNING

Indicates a hazard with a moderate level of risk, which, if not avoided, will result in death or serious injury.

CAUTION

Indicates a hazard with a low level of risk, which, if not avoided, may result in minor or slight injury or property damage.

1.2.4 Information notes

Information notes contain important instructions for the installation and problem-free operation of the drive controller. These must be followed at all times. The information notes also point out that failure to observe may result in damage to property or financial damages.





IMPORTANT INFORMATION

The drive controller may only be assembled, operated, maintained and installed by trained and qualified staff.

Fig.: 2 Example of an information note

Symbols within the information notes

Symbol	Meaning
	Important information
	Damage to property possible

Other notes

Symbol	Meaning
	INFORMATION
	Enlarged view

1.3 Symbols used in this manual


Symbol	Meaning
1., 1., 3. ...	Consecutive steps in a handling instruction
	Effect of a handling instruction
✓	Final result of a handling instruction
■	List

Fig.: 3 Symbols and icons used

Abbreviations used

Abbreviation	Explanation
Tab.	Table
Fig.	Figure
It.	Item
Ch.	Chapter

1.4 Labels on the drive controller




Fig.: 4 Type plate on the drive controller

Signs and labels are affixed to the drive controller. These may not be altered or removed.

Symbol	Meaning
	Danger due to electrical shock and discharge
	Danger due to electrical shock and discharge. Wait two minutes (discharge time of the capacitors) after shut-down
	Additional earth connection
	Observe and read operating manual

1.5 Qualified staff

In the context of this operating manual, qualified staff refers to electronics specialists who are familiar with the installation, assembly, commissioning and operation of the drive controller and the dangers involved, and whose specialist training and knowledge of relevant standards and regulations provide them with the necessary abilities.

1.6 Proper use

If the device is installed in a machine, drive controllers may not be commissioned (i.e. intended operation may not begin) until it has been determined that the machine complies with the regulations of EC Directive 2006/42/EC (Machinery Directive); DIN EN 60204-1; VDE 0113-1:2007-06 must be observed.

Commissioning (i.e. beginning intended operation) is only permitted if the EMC Directive (2004/108/EC) is complied with.

The harmonised standards of DIN EN 50178; VDE 0160:1998-04 must be applied for this drive controller along with DIN EN 60439-1; VDE 0660-500:2005-01.

This drive controller may not be operated in areas where there is a danger of explosion!

Repairs may only be performed by authorised repair bodies. Independent and unauthorised intervention may result in death, injury or property damage. The warranty provided by KOSTAL will be invalidated in such cases.



IMPORTANT INFORMATION

Using drive controllers in equipment that is not fixed is considered as an exceptional environmental condition and is only permitted if allowed by the standards and guidelines applicable on site.

1.7 Responsibility

As a basic principle, electronic devices are not fail-safe. The operator and/or the contractor setting up the machine or system is responsible for ensuring that the drive switches to a safe state if the device fails.

The “Electrical equipment of machines” section in DIN EN 60204-1; VDE 0113-1:2007-06, “Safety of machinery” describes the safety requirements for electrical control units. These are provided for the safety of people and machines and must be observed in order to retain the functional capability of the machine or system.

An emergency stop feature does not have to result in the voltage supply to the drive being switched off. To avoid dangerous situations, it may be useful for individual drives to remain operational or for specific safety procedures to be initiated. The effectiveness of emergency stop measures is evaluated by means of a risk assessment for the machine or system and its electrical equipment, and is determined by selecting a circuit category according to DIN EN 13849 “Safety of machinery – Safety-related parts of control systems”.

1.8 EU Declaration of Conformity

KOSTAL Industrie Elektrik GmbH hereby declares that the drive controller described in this document complies with the basic requirements and other relevant conditions of the directives listed below.

- Directive 2014/30/EU
on the approximation of the laws of the Member States relating to electromagnetic compatibility (EMC)
- Directive 2014/35/EU
on the harmonisation of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits – for short: Low Voltage Directive)
- Directive 2011/65/EU
(to limit the use of certain hazardous substances in electrical and electronic equipment – in short: RoHS)

The declaration of conformity for the M product family of the INVEOR serves as an example. This can be found at:

<https://www.kostal-industrie-elektrik.com/downloads>



IMPORTANT INFORMATION

INVEOR P is a component solely intended for installation in the final application during the distributor's installation.

Electrical safety is heavily dependent on the precautionary measures taken by the distributor during installation in the final application.



IMPORTANT INFORMATION

CE marking is the sole responsibility of the distributor.

Note the project planning information (chapter 1.9) for details.

1.9 Project planning information for housing design

The following information should help you produce the housing design.



IMPORTANT INFORMATION

Compliance with all project planning information is the sole responsibility of the system integrator!



IMPORTANT INFORMATION

Contact surface to the cooler

The drive controller can either be cooled by a sufficiently large installation plate or an additional cooler.

Evenness required of contact surface = 0.05 mm

Maximum roughness of contact surface = RZ 6



IMPORTANT INFORMATION

Applying the thermal conductivity paste

Coat the surfaces between the installation plate (Cold Plate) and cooler with thermal conductivity paste (layer thickness 30 – 70 µ).

Article no. of thermal conductivity paste 10139778



IMPORTANT INFORMATION

"IGBT temperature" shutdown threshold

IGBT module at transition to cooling element.

If the cooling element is not adequately dimensioned or if heat transfer between the INVEOR installation plate and cooling element provided by the customer is not properly implemented (thermal conductivity paste not used or poorly applied, foreign bodies on cooling surface), the drive controller shuts down at 95 °C (measured in the power module) with the error message "IGBT temperature".



IMPORTANT INFORMATION

"Interior temperature" shutdown threshold

Temperature in device interior

If the temperature in the device interior is too high because the removal of lost heat via the housing has been inadequately dimensioned, the drive controller shuts down at an interior temperature of 85 °C. The "Interior temperature" error message is displayed.



IMPORTANT INFORMATION

"Interior temperature" shutdown threshold

Testing the heat transfer

The heat transfer and installation on the customer's cooling element must be verified during the prototype phase by a customer test.

Active cooling plate dimensions

Size	Output [kW]	Active cooling surfaces	
		B [mm]	H [mm]
Alpha	0.75	120	210
A	1.5	150	261.5
B	4.0	185	300
C	7.5	220	330
D	22	270	343



Max. thermal resistance of customer's cooler

- Rated output of size

Size	Performance categories	Rth [K/W]	For ambient temp.
Alpha, 1 x 230 VAC	PW04 → 0.75 kW	0.688	50 °C
A, 1 x 230 VAC	PW05 → 1.10 kW	0.186	50 °C
A, 3 x 400 VAC	PW06 → 1.50 kW	0.431	50 °C
B, 3 x 400 VAC	PW07 → 4.00 kW	0.280	50 °C
C, 3 x 400 VAC	PW11 → 7.50 kW	0.117	50 °C
D, 3 x 400 VAC	PW13 → 15.00 kW	0.087	40 °C
D, 3 x 400 VAC	PW15 → 22.00 kW	0.037	40 °C



IMPORTANT INFORMATION

Active cooling of size D is recommended to reduce the size of the cooling element.



DANGER!

Risk of death due to electrical shock!
Death or serious injury!

Spacing and insulation

The power-conducting plate and parts of the application PCB have a potential of up to 400 V to PE (housing).

Spacing of 10 mm should therefore be planned between the metallic housing and printed circuit boards and between components on the printed circuit boards and the 20-pin ribbon cable.

Use an insulating film with a voltage resistance of at least 600 V at points where this spacing isn't provided.

**WARNING!**

Risk of death due to electrical shock!

Death or serious injury!

Degree of contamination

The INVEOR P drive controller may only be installed in housings complying with at least degree of contamination 2.

This is usually ensured by the IP55 housing (or larger).

Customers must create equivalent or better conditions (degree of contamination 1) in their housings.

Key for degree of contamination 1

Only dry, non-conductive contamination is present if any, e.g. in clean, dry rooms or rooms with air conditioning.

Key for degree of contamination 2

Only non-conductive contamination is present. Temporary conductivity caused by condensation must be expected occasionally, e.g. in laboratories, precision mechanics workshops, test fields, sales showrooms.

**DANGER!**

Risk of death due to electrical shock!

Death or serious injury!

Live parts

Attach a warning notice in accordance with IEC 60417-5036 (2002-10) to the last housing part removed (with tool) before accessing live parts.

DANGER!

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted.



Danger due to electrical shock and discharge.

Wait two minutes (discharge time of the capacitors) after shut-down

Fitting the warning notice is the sole responsibility of the system integrator!

WARNING!

Fire hazard due to short-circuit current!

Serious burns!

In sizes C and D, the brake chopper – IGBT is smaller than the rest of the output stage.

Because the preliminary fuses are designed for the nominal values of the output stage, it is very possible that the fuse will not trip directly and the brake chopper's short-circuit current will exist for a long time.

Fires may result.

The INVEOR standard housing is not critical in this regard.

1.9.1 Project planning information for housing design for STO variant



IMPORTANT INFORMATION

The INVEOR P with functional safety is just one component in the final application. As a result, the STO function of the INVEOR P must be approved separately in the final application.

The design of the housing design must satisfy the following conditions.

Protection from pollution



IMPORTANT INFORMATION

With open housing, pollution degree 2 must be observed in order to ensure the safety function.

Elimination of errors



IMPORTANT INFORMATION

The STO connection line must be shielded in order that the elimination of errors with regard to external voltage coupling may be applied. EMC screw connections must be used for the cable inlet into the housing.

Elimination of errors with regard to short circuit



IMPORTANT INFORMATION

With reference to the STO connection line, the "elimination of errors with regard to short circuit" is achieved in accordance with DIN EN 13849-2 in that a separate, shielded cable is used for each channel. Shielding is to be applied at both ends. The EMC screw connections provided must be used for this purpose.



IMPORTANT INFORMATION

If only one shielded cable is used for both STO channels, a safety switching device must be used to detect possible crossovers between the channels to qualify for observation of the "elimination of errors short circuit" in accordance with DIN EN 13849-2.

Visual inspection**IMPORTANT INFORMATION**

All cables are to be inspected for correct wiring prior to commissioning.

Loss of the safety function**IMPORTANT INFORMATION**

Permanent 24 V voltage to the STO inputs results in the loss of the safety function.

EMC approval**IMPORTANT INFORMATION**

EMC approval has been carried out for the entire INVEOR system.

In exceptional cases, individual tests may have to be repeated. When undertaking the individual test, take account of the more stringent requirements for “functional safety”.

Approval**IMPORTANT INFORMATION**

The entire system must be approved by a named body.

The INVEOR system itself has been certified by TÜV Rheinland.

1.10 Safety instructions

The following warnings, precautionary measures and information are provided for your safety and serve to prevent damage to the drive controller and the components connected to it. This chapter contains warnings and information that are generally applicable when handling drive controls. They are split into general information, transport & storage and dismantling & disposal.

Specific warnings and comments that apply to specific activities can be found at the start of the appropriate chapters and are repeated or added to at various critical points in these chapters.

Please read this information carefully as it is provided for your personal safety and will also prolong the life of the drive controller and connected devices.

1.10.1 General information



IMPORTANT INFORMATION

Carefully read this operating manual and the warning signs affixed to the drive controller before installation and commissioning. Make sure that all warning signs on the drive controller are legible; replace any missing or damaged signs.

They contain important information on the installation and operation of the drive controller. In particular, note the information in the "Important information" chapter. KOSTAL Industrie Elektrik GmbH assumes no liability for damages arising from the non-observance of this operating manual.

This operating manual is an integral part of the product. It applies exclusively to the drive controller from KOSTAL Industrie Elektrik GmbH.

Keep the operating manual close to the drive controller so it is easily accessible to all users.

**IMPORTANT INFORMATION**

The drive controller can only be operated safely if the required environmental conditions listed in the “Suitable environmental conditions” chapter are met.

**DANGER!**

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted.

**DANGER!**

Risk of death due to revolving mechanical parts!

Death or serious injury!

De-energise drive controller and secure it against being restarted.

**DANGER!**

Risk of death due to fire or electrical shock!

Death or serious injury!

Always use the drive controller as intended.

Do not modify the drive controller.

Only use spare parts and accessories sold or recommended by the manufacturer.

During assembly, ensure a sufficient distance from neighbouring parts.

CAUTION!

Risk of burns from hot surfaces!

Serious burns to the skin from hot surfaces!

Allow the drive controller's cooling elements to cool sufficiently.

Allow the neighbouring parts to cool sufficiently.

If necessary, install protection against accidental contact.

1.10.2 Transport & storage



Damage to property possible

Risk of damage to drive controller!

Risk of damage to drive controller from improper transport, storage, installation and assembly!

Transport the drive controller properly in its original packaging on a pallet.

Always store the drive controller properly.

Only allow qualified staff to undertake installation and assembly.

1.10.3 Long –term storage



IMPORTANT INFORMATION

If devices with a single-phase feed-in have been in storage for more than 2 years, the following regeneration process is required before installation / use under the nominal conditions:

- The drive controller must be connected to supply voltage (+/- 3 %) for 30 minutes without the device being loaded. This applies to the motor connection as well as possible consumers and connections to the application.
- Perform this process once before commissioning.

In all cases, observe the general requirements for storing drive controllers!

1.10.4 Information about commissioning



DANGER!

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted.

The following terminals may lead to dangerous currents even when the motor is not running

Supply terminals	X1	(INV. Alpha-A): L, N
	X1	(INV. A-D): L1, L2, L3
Motor connection terminals	X411	(INV. Alpha): U, V, W
	X4	(INV. A-D): U, V, W
Relay connection terminals	X6, X7	
PTC terminals	T1 / T2	



IMPORTANT INFORMATION

- Only use mains connections with hardwiring.
- Ground the drive controller in accordance with DIN EN 61140.
- The INVEOR P may have touch currents of > 3.5 mA.
In accordance with DIN EN 61800-5-1, an extra protective grounding conductor of the same cross-section as the original protective grounding conductor should therefore be fitted. A second protective grounding conductor can be connected under the mains supply (position marked with a ground symbol) on the outside of the device. A suitable M6x15 screw (4.0 Nm torque) is provided with the adapter plate.
- If three-phase frequency inverters are used, it is not permitted to use standard type A FI protection switches, or RCDs (residual current-operated protective devices) to protect against direct or indirect contact. According to DIN VDE 0160 and EN 50178, the FI protection switch must be universal current sensitive (RCD type B)

**IMPORTANT INFORMATION**

- If different voltages are used (e.g. +24 V/230 V), crossing cable runs are not permitted under any circumstances. The operator must also ensure compliance with the applicable regulations (e.g. double or reinforced insulation acc. to DIN EN 61800-5-1).
- The drive controller contains components susceptible to electrical discharge. These may be destroyed through improper handling. Therefore, precautionary measures against electrostatic charges must be taken when work is performed on these components.

1.10.5 Instructions concerning operation**DANGER!**

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted.

**DANGER!**

Risk of death due to revolving mechanical parts!

Death or serious injury!

De-energise drive controller and secure it against being restarted.

**IMPORTANT INFORMATION**

Observe the following instructions during operation:

- The drive controller runs at high voltages.
- When electrical devices are operated, some of their parts are always subject to dangerous voltage.
- Emergency stop equipment according to DIN EN 60204-1; VDE 0113-1:2007-06 must function in all the control device's operating modes. Resetting the emergency stop equipment may not result in uncontrolled or undefined restarting.
- In order to ensure safe disconnection from the mains, the mains cable has to be fully disconnected from the drive controller in a synchronous manner.
- A pause of at least 1 to 2 mins must be observed between consecutive mains activations for devices with a single-phase feed and for size D (11 to 22 kW).
- A pause of at least 3 sec. must be observed between consecutive grid connections for devices with three-phase feed-in in sizes A - C (0.55 to 7.5 kW).
- Certain parameter settings may result in the drive controller restarting automatically after the supply voltage has failed.

**Damage to property possible**

If the information is not observed, the drive controller could be damaged and destroyed during subsequent commissioning.

Observe the following instructions during operation:

- The motor parameters, especially the I2T settings, have to be configured properly to provide proper motor overload protection.
- The drive controller has internal motor overload protection. See parameters 33.010 and 33.011.
I2T is ON by default. Motor overload protection can also be ensured via an external PTC.
- The drive controller may not be used as "Emergency stop equipment" (see DIN EN 60204-1; VDE 01131:2007-06).

1.10.6 Maintenance and inspection

The drive controllers may only be maintained and inspected by electricians with recognised training. Unless explicitly described in this operating manual, changes to hardware and software may only be undertaken by KOSTAL experts or persons authorised by KOSTAL.

Measurement of insulation resistance on control part

An insulation test on the control card's input terminals is not permitted.

1.10.7 Repairs



Damage to property possible

If the information is not observed, the drive controller could be damaged and destroyed during subsequent commissioning.

- Repairs to the drive controller may only be performed by the KOSTAL Service department.

CAUTION!



Risk of burns from hot surfaces!

Serious burns to the skin from hot surfaces!

Allow the drive controller's cooling elements to cool sufficiently.

DANGER!



Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted.



Danger due to electrical shock and discharge.

Wait two minutes (discharge time of the capacitors) after shut-down.

2. Overview of the drive controller

2.1	Model description size Alpha, size A - D	31
2.2	Scope of delivery	32
2.2.1	Scope of delivery for INVEOR P size Alpha.....	32
2.2.2	Scope of delivery for INVEOR P size A - D	33
2.3	Description of INVEOR P drive controller.....	34

This chapter contains information on the scope of delivery for the drive controller and the function description.

2.1 Model description size Alpha, size A - D

	Drive controller type, size							
INV P α	Inverter Plate, size Alpha							
INV P A	Inverter Plate, size A							
INV P B	Inverter Plate, size B							
INV P C	Inverter Plate, size C							
INV P D	Inverter Plate, size D							
		Grid voltage						
	IV01	400 V						
	IV02	230 V						
			Recommended motor rating					
		PW04	0.75 kW					
		PW05	1.10 kW					
		PW06	1.50 kW					
		PW09	4.00 kW					
		PW11	7.50 kW					
		PW13	15.00 kW					
		PW15	22.00 kW					
			Power-conducting plate					
		LP01	without brake chopper					
		LP02	with brake chopper					
		LP03	without brake chopper					
		LP04	with brake chopper					
			Application PCB					
		AP01	Standard					
		AP03	Basic					
		AP05	Standard + CANopen					
		AP06	Standard + EtherCAT					
		AP09	Standard + PROFINET					
		AP12	Standard					
		AP13	Standard + CANopen					
		AP14	Standard + Sercos III					
		AP16	Standard + PROFIBUS COMX (as of SW3.8x)					
				Housing type				
			GH03	Sandwich				
				Cover type				
				DK03	without cover			
						Model		
					CO00	KOSTAL - standard		
INV Px	IVxx	PWxx	LPxx	APxx	GHxx	DKxx	COxx	

α	A	B	C	D
	x	x	x	x
x	x			
α	A	B	C	D
x				
	x			
	x			
		x		
			x	
				x
				x
α	A	B	C	D
x	x	x	x	
	x	x		
				x
			x	x
α	A	B	C	D
	x	x	x	x
	x	x	x	
	x	x	x	x
	x	x	x	x
x				
x				
	x	x	x	x
	x	x	x	x
α	A	B	C	D
x	x	x	x	x
α	A	B	C	D
x	x	x	x	x

2.2 Scope of delivery

Once you have received the product, please ensure that the delivery is complete.

2.2.1 Scope of delivery for INVEOR P size Alpha




Fig.: 5 Scope of delivery for INVEOR P size Alpha

Key			
Drive controller article number		Adapter plate article number	
1	INVEOR P drive controller size Alpha	4	Motor terminal
2	Mains terminal	5	Operating manual
3	Bridge	6	M5 x 12 PE screw

2.2.2 Scope of delivery for INVEOR P size A - D




Fig.: 6 Scope of delivery for INV P size A - D

Key			
Drive controller article number		Adapter plate article number	
1	INVEOR P drive controller size A IV02 or	5	INVEOR P drive controller size D IV01
2	INVEOR P drive controller size A IV01 or	6	M5 x 12 PE screw
3	INVEOR P drive controller size B IV01 or	7	Operating manual
4	INVEOR P drive controller size C IV01 or		

2.3 Description of INVEOR P drive controller

The INVEOR P drive controller is a device for speed control in three-phase AC motors.

The permitted ambient temperatures specified in the technical data refer to operation at nominal load.

3. Installation

3.1	Safety instructions for installation	36
3.2	Recommended preliminary fuses / line protection	37
3.3	Installation requirements for INVEOR P size Alpha	38
3.3.1	Suitable ambient conditions (see chapter 1.9)	38
3.3.2	Basic connection versions/power connections (INVEOR P size Alpha)	39
3.3.3	Basic connection versions/power connections (INVEOR P size A 1 IV02 [1 x 230 V AC])	41
3.3.4	Basic connection versions/power connections (INVEOR P size A IV01 [3 x 400 V AC])	43
3.3.5	Basic connection versions (INVEOR P size B IV01 [3 x 400 V AC])	45
3.3.6	Basic connection versions (INVEOR P size C IV01 [3 x 400 V AC])	47
3.3.7	Basic connection versions (INVEOR P size D IV01 [3 x 400 V AC])	49
3.3.8	Short circuit and ground protection	51
3.3.9	Requirements of the brake resistors to use	51
3.4	Wiring instructions	52
3.4.1	Wiring instructions for control terminals INVEOR P size Alpha	52
3.4.2	Wiring instructions for control terminals INVEOR P size A-D	53
3.4.3	Preventing electromagnetic interferences	54
3.5	Installing the INVEOR P	55
3.5.1	Mechanical installation	55
3.5.2	Wiring diagram for INVEOR P size Alpha	56
3.5.3	Electrical installation for INVEOR P size Alpha	57
3.5.4	Electrical installation for INVEOR P size A-B	61
3.5.5	Electrical installation for INVEOR P size C-D	64
3.5.6	Connection diagram for INVEOR P size A-D	67

3.1 Safety instructions for installation

DANGER



Risk of death due to revolving mechanical parts!

Death or serious injury!

De-energise drive controller and secure it against being restarted.

Only allow appropriately qualified staff to install the drive controller.

Only use staff who are trained in mounting, installation, commissioning and handling.

Always ground the device in accordance with DIN EN 61140; VDE 0140, NEC and other relevant standards.

Mains connections must be hardwired.

CAUTION




Risk of burns from hot surfaces!

Serious burns to the skin from hot surfaces!

Allow the drive controller's cooling elements to cool sufficiently.

3.2 Recommended preliminary fuses / line protection

INVEOR P	Size Alpha 1 x 230 V AC	Size A 1 x 230 V AC	Size A 3 x 400 V AC	Size B 3 x 400 V AC	Size C 3 x 400 V AC	Size D 3 x 400 V AC	Size D 3 x 400 V AC
Nominal motor rating	up to 0.75 kW	up to 1.1 kW	up to 1.5 kW	up to 4.0 kW	up to 7.5 kW	up to 15 kW	up to 22 kW
Mains current	7.3 A	9.2 A	3.3 A	7.9 A	14.8 A	28.2 A	39.9 A
Mains current 150% (overload 60 s)	10.95 A	13.8 A	4.95 A	11.85 A	22.2 A	42.3 A	51.87 A
Line circuit breaker – recommendation	C 16	C 16	C 10	C 16	C 25	C 50	C 63
	Characteristics C = line circuit breaker tripping between 6 – 10 times I_n						
	The cross-section of the supply line must be designed according to the transfer category and maximum permitted current. The contractor commissioning the device must ensure protection for the power line.						

3.3 Installation requirements for INVEOR P size Alpha

3.3.1 Suitable ambient conditions (see chapter 1.9)

Conditions	Values
Altitude of the installation location:	up to 1000 m AMSL
Ambient temperature: Size Alpha, A, B, C	- 25 °C to + 50 °C
Ambient temperature: Size D	- 25 °C to + 40 °C
Relative air humidity	≤ 96 %, condensation not permitted.
Cooling:	Surface cooling, realised in the customer application.

Tab. 1: Ambient conditions

Ensure that the housing type (protection type) is suitable for the operating environment.

Ensure that the surfaces between the installation plate (Cold Plate) and cooler are coated with thermal conductivity paste (layer thickness 30 – 70 µ).



Damage to property possible

Failure to comply with this requirement may eventually result in the loss of the protection type (particularly in respect to seals and fibre-optic elements).

- Disassembling the circuit boards renders the warranty void!
- Mounting points and sealing surfaces must be kept free of paint for purposes of EMC and grounding!

3.3.2 Basic connection versions/power connections (INVEOR P size Alpha)




Fig.: 7 Basic connection version (INVEOR P size Alpha)

Terminal assignment X411 (motor)

U	U1
V	V1
W	W1
PE	PE
T1, T2	Connect bridge (see scope of delivery)

Terminal assignment X1 (mains connection)

L	Mains phase
N	Neutral wire
PE	Earth connection point



DANGER

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted

Size Alpha	
X1 mains + X6 relay + X411 motor / PTC	The terminals for the mains cable are located on the IPM printed circuit board (1) and/or on the application board (2). The configuration may vary depending on the version.
	Core end sleeves with plastic collars and lugs are recommended.
	Terminals: Spring force connection (slot screwdriver, max. width 2.5 mm)
	Conductor cross-section, flexible: min. 0.2 mm ² max. 2.5 mm ²
	Conductor cross-section, flexible with core end sleeve without and with plastic sleeve: min. 0.25 mm ² max. 2.5 mm ²
	2 conductors of the same cross-section, flexible with TWIN-AEH with plastic sleeve: min. 0.25 mm ² max. 1.25 mm ²
	Conductor cross-section AWG: min. 30 max. 12
Length of stripped insulation: 10 mm	



Damage to property possible

Risk of damage to the drive controller.

Correct phase assignment must be observed when connecting the drive controller, otherwise the motor may be overloaded.



IMPORTANT INFORMATION

If a thermal resistor (PTC or Klixon) is not used, the bridging contact inserted for delivery must be connected.

The cross-section of the supply line must be designed according to the transfer category and maximum permitted current. The contractor commissioning the device must ensure protection for the power line.

3.3.3 Basic connection versions/power connections (INVEOR P size A 1 IV02 [1 x 230 V AC])




Fig.: 8 Basic connection versions (INVEOR P size A IV02)

Terminal assignment X1 (mains connection)	
L1	Mains phase
N	Neutral wire
PE	Earth connection point
Terminal assignment X3 (optional)	
Connection for external brake resistor (+)	
Connection for external brake resistor (-)	
Terminal assignment X4	
U	Motor phase U
V	Motor phase V
W	Motor phase W
Terminal assignment X11 (option)	
1	Motor temperature (-)
2	Motor temperature (+)
Terminal assignment X15	
PE	Earth connection point



DANGER

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted

Size A	
X1 mains + B - brake resistor	The terminals for the mains cable (X1) are located on the IPM printed circuit board. The INVEOR P also has the option of being equipped with terminals (X3) for connecting a brake resistor. The configuration may vary depending on the version.
	Core end sleeves with plastic collars and lugs are recommended.
	Terminals: Spring force connection (slot screwdriver, max. width 2.5 mm)
	Conductor cross-section, rigid min. 0.2 mm ² max. 10 mm ²
	Conductor cross-section, flexible min. 0.2 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve without plastic sleeve min. 0.25 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve with plastic sleeve min. 0.25 mm ² max. 4 mm ²
	2 conductors of the same cross- section, flexible with TWIN-AEH with plastic sleeve min. 0.25 mm ² max. 1.5 mm ²
	AWG/kcmil conductor cross-section according to UL/CUL min. 24 max. 8
	Length of stripped insulation: 15 mm



IMPORTANT INFORMATION

When connecting a brake resistor to an optional braking module, cables with shielding and double insulation must be used!



Damage to property possible

Risk of damage to the drive controller.

Correct phase assignment must be observed when connecting the drive controller, otherwise the motor may be overloaded.



IMPORTANT INFORMATION

If a thermal resistor (PTC or Klixon) is not used, the bridging contact inserted for delivery must be connected.

The cross-section of the supply line must be designed according to the transfer category and maximum permitted current. The contractor commissioning the device must ensure protection for the power line.

3.3.4 Basic connection versions/power connections (INVEOR P size A IV01 [3 x 400 V AC])




Fig.: 9 Basic connection versions (INVEOR P size A IV01)

Terminal assignment X1 (mains connection)	
L1	Mains phase L1
L2	Mains phase L2
L3	Mains phase L3
PE	Earth connection point
Terminal assignment X3 (optional)	
Connection for external brake resistor (+)	
Connection for external brake resistor (-)	
Terminal assignment X4	
U	Motor phase U
V	Motor phase V
W	Motor phase W
Terminal assignment X11 (option)	
1	Motor temperature (-)
2	Motor temperature (+)
Terminal assignment X15	
PE	Earth connection point



DANGER

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted

Size A	
X1 mains + B - brake resistor	The terminals for the mains cable (X1) are located on the IPM printed circuit board. The INVEOR P also has the option of being equipped with terminals (X3) for connecting a brake resistor. The configuration may vary depending on the version.
	Core end sleeves with plastic collars and lugs are recommended.
	Terminals: Spring force connection (slot screwdriver, max. width 2.5 mm)
	Conductor cross-section, rigid min. 0.2 mm ² max. 10 mm ²
	Conductor cross-section, flexible min. 0.2 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve without plastic sleeve min. 0.25 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve with plastic sleeve min. 0.25 mm ² max. 4 mm ²
	2 conductors of the same cross- section, flexible with TWIN-AEH with plastic sleeve min. 0.25 mm ² max. 1.5 mm ²
	AWG/kcmil conductor cross-section according to UL/CUL min. 24 max. 8
	Length of stripped insulation: 15 mm



IMPORTANT INFORMATION

When connecting a brake resistor to an optional braking module, cables with shielding and double insulation must be used!



Damage to property possible

Risk of damage to the drive controller.

Correct phase assignment must be observed when connecting the drive controller, otherwise the motor may be overloaded.



IMPORTANT INFORMATION

If a thermal resistor (PTC or Klixon) is not used, the bridging contact inserted for delivery must be connected.

The cross-section of the supply line must be designed according to the transfer category and maximum permitted current. The contractor commissioning the device must ensure protection for the power line .

3.3.5 Basic connection versions (INVEOR P size B IV01 [3 x 400 V AC])




Fig.: 10 Basic connection versions (INVEOR P size B IV01)

Terminal assignment X1 (mains connection)	
L1	Mains phase L1
L2	Mains phase L2
L3	Mains phase L3
PE	Earth connection point
Terminal assignment X3 (optional)	
Connection for external brake resistor (+)	
Connection for external brake resistor (-)	
Terminal assignment X4	
U	Motor phase U
V	Motor phase V
W	Motor phase W
Terminal assignment X11 (option)	
1	Motor temperature (-)
2	Motor temperature (+)
Terminal assignment X15	
PE	Earth connection point



DANGER

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted

Size B	
X1 mains + B - brake resistor	The terminals for the mains cable (X1) are located on the IPM printed circuit board. The INVEOR P also has the option of being equipped with terminals (X3) for connecting a brake resistor. The configuration may vary depending on the version.
	Core end sleeves with plastic collars and lugs are recommended.
	Terminals: Spring force connection (slot screwdriver, max. width 2.5 mm)
	Conductor cross-section, rigid min. 0.2 mm ² max. 10 mm ²
	Conductor cross-section, flexible min. 0.2 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve without plastic sleeve min. 0.25 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve with plastic sleeve min. 0.25 mm ² max. 4 mm ²
	2 conductors of the same cross- section, flexible with TWIN-AEH with plastic sleeve min. 0.25 mm ² max. 1.5 mm ²
	AWG/kcmil conductor cross-section according to UL/CUL min. 24 max. 8
	Length of stripped insulation: 15 mm



IMPORTANT INFORMATION

When connecting a brake resistor to an optional braking module, cables with shielding and double insulation must be used!



Damage to property possible

Risk of damage to the drive controller.

Correct phase assignment must be observed when connecting the drive controller, otherwise the motor may be overloaded.



IMPORTANT INFORMATION

If a thermal resistor (PTC or Klixon) is not used, the bridging contact inserted for delivery must be connected.

The cross-section of the supply line must be designed according to the transfer category and maximum permitted current. The contractor commissioning the device must ensure protection for the power line .

3.3.6 Basic connection versions (INVEOR P size C IV01 [3 x 400 V AC])




Fig.: 11 Basic connection versions (INVEOR P size C IV01)

Terminal assignment X1 (mains connection)	
L1	Mains phase L1
L2	Mains phase L2
L3	Mains phase L3
PE	Earth connection point
Terminal assignment X3 (optional)	
Connection for external brake resistor (+)	
Connection for external brake resistor (-)	
Terminal assignment X4	
U	Motor phase U
V	Motor phase V
W	Motor phase W
Terminal assignment X11 (option)	
1	Motor temperature (-)
2	Motor temperature (+)
Terminal assignment X5	
PE	Earth connection point



DANGER

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted

Size C	
X1 mains + B - brake resistor	The terminals for the mains cable (X1) are located on the IPM printed circuit board. The INVEOR P also has the option of being equipped with terminals (X3) for connecting a brake resistor. The configuration may vary depending on the version.
	Core end sleeves with plastic collars and lugs are recommended.
	Terminals: Spring force connection (slot screwdriver, max. width 2.5 mm)
	Conductor cross-section, rigid min. 0.2 mm ² max. 10 mm ²
	Conductor cross-section, flexible min. 0.2 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve without plastic sleeve min. 0.25 mm ² max. 6 mm ²
	Conductor cross-section, flexible with core end sleeve with plastic sleeve min. 0.25 mm ² max. 4 mm ²
	2 conductors of the same cross-section, flexible with TWIN-AEH with plastic sleeve min. 0.25 mm ² max. 1.5 mm ²
	AWG/kcmil conductor cross-section according to UL/CUL min. 24 max. 8
	Length of stripped insulation: 15 mm



IMPORTANT INFORMATION

When connecting a brake resistor to an optional braking module, cables with shielding and double insulation must be used!



Damage to property possible

Risk of damage to the drive controller.

Correct phase assignment must be observed when connecting the drive controller, otherwise the motor may be overloaded.



IMPORTANT INFORMATION

If a thermal resistor (PTC or Klixon) is not used, the bridging contact inserted for delivery must be connected.

The cross-section of the supply line must be designed according to the transfer category and maximum permitted current. The contractor commissioning the device must ensure protection for the power line .

3.3.7 Basic connection versions (INVEOR P size D IV01 [3 x 400 V AC])




Fig.: 12 Basic connection versions (INVEOR P size D IV01)

Terminal assignment X1 (mains connection)

L1	Mains phase L1
L2	Mains phase L2
L3	Mains phase L3
PE	Earth connection point

Terminal assignment X2 (optional)

- Connection for external brake resistor (+)
- Connection for external brake resistor (-)

Terminal assignment X4

PE	Earth connection point
U	Motor phase U
V	Motor phase V
W	Motor phase W

Terminal assignment X11

1	Motor temperature (-)
2	Motor temperature (+)



DANGER

Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted

Size D	
X1 mains + B - brake resistor	The terminals for the mains cable (X1) are located on the IPM printed circuit board. The INVEOR P also has the option of being equipped with terminals (X2) for connecting a brake resistor. The configuration may vary depending on the version.
	Core end sleeves with plastic collars and lugs are recommended.
	Torque min. 2.5 Nm / max. 4.5 Nm
	Conductor cross-section: rigid min. 0.5 mm ² / rigid max. 35 mm ²
	Conductor cross-section, flexible: min. 0.5 mm ² / max. 25 mm ²
	Conductor cross-section, flexible with core end sleeve without plastic collar min. 1 mm ² max. 25 mm ²
	Conductor cross-section, flexible with core end sleeve with plastic collar min. 1.5 mm ² max. 25 mm ²
	AWG/kcmil conductor cross-section according to UL/CUL min. 20 max. 2
	2 conductors of the same cross-section, rigid min. 0.5 mm ² max. 6 mm ²
	2 conductors of the same cross-section, flexible min. 0.5 mm ² max. 6 mm ²
	2 conductors of the same cross-section, flexible with AEH without plastic sleeve min. 0.5 mm ² max. 4 mm ²
	2 conductors of the same cross-section, flexible with TWIN-AEH with plastic sleeve min. 0.5 mm ² max. 6 mm ²
	AWG according to UL/CUL min. 20 max. 2



IMPORTANT INFORMATION

When connecting a brake resistor to an optional braking module, cables with shielding and double insulation must be used!



Damage to property possible

Risk of damage to the drive controller.

Correct phase assignment must be observed when connecting the drive controller, otherwise the motor may be overloaded.



IMPORTANT INFORMATION

If a thermal resistor (PTC or Klixon) is not used, the bridging contact inserted for delivery must be connected.

The cross-section of the supply line must be designed according to the transfer category and maximum permitted current. The contractor commissioning the device must ensure protection for the power line.

3.3.8 Short circuit and ground protection

The drive controller contains an internal short circuit and ground protection.

3.3.9 Requirements of the brake resistors to use

For safe operation of the "brake chopper" option, inherently safe brake resistors must be used.

Inherently safe, wire-based resistors:

The inherently safe brake resistor prevents the following in the event of long-lasting overload, such as a short circuit of the brake IGBT (brake chopper):

- Short circuit
- Short circuit to earth / earth fault
- Fire
- Explosion
- Melting of aluminium housing of resistor

3.4 Wiring instructions

3.4.1 Wiring instructions for control terminals
INVEOR P size Alpha

The control connections are located on the application board.
The configuration may vary depending on the version.




Fig.: 13 Control terminals (size Alpha)

Size Alpha		
X5 – X6	Terminals:	Plug terminal clamp with activation button (slot screwdriver, max. width 2.5 mm)
	[X5] Connection cross-section:	0.14 to 1.5 mm ² , fine-wired, AWG 30 to AWG 16
	[X6] Connection cross-section:	0.2 to 2.5 mm ² , fine-wired, AWG 30 to AWG 12
	Connection cross-section:	0.5 to 1.0 mm ² , fine-wired (core end sleeves with and without plastic collars)
	Length of stripped insulation:	9 to 10 mm

For technical data on power connections, see chapter 3.3.2.

3.4.2 Wiring instructions for control terminals INVEOR P size A-D

The control connections are located on the application board.

The configuration may vary depending on the version.




Fig.: 14 Wiring instructions for control terminals INVEOR P size A-D

Sizes A - D		
X5 - X7	Terminals:	Plug terminal clamp with activation button (slot screwdriver, max. width 2.5 mm)
	Connection cross-section:	0.5 to 1.5 mm ² , single-wire, AWG 20 to AWG 14
	Connection cross-section:	0.75 to 1.5 mm ² , fine-wired, AWG 18 to AWG 14
	Connection cross-section:	0.5 to 1.0 mm ² , fine-wired (core end sleeves with and without plastic collars)
	Length of stripped insulation:	9 to 10 mm

3.4.3 Preventing electromagnetic interferences

Where possible use shielded lines for control circuits.

The shielding should be applied to the line end with special care and without laying the leads across longer stretches without shielding.

Ensure that no parasitic currents (compensating currents etc.) can flow via the analogue cable's shielding.

Route the control lines as far away as possible from the power lines. Under certain circumstances, separate power ducts should be used.

If lines do cross, an angle of 90° should be observed.

Upstream circuit elements, such as protector switches and brake coils, or circuit elements that are operated via the outputs of the drive controller have to be interference-suppressed. RC circuits are suitable as AC voltage protector switches, while free-wheeling diodes or varistors are usually used as DC voltage protector switches. These interference suppression devices are attached directly to the protector switch coils.



IMPORTANT INFORMATION

Where possible, the power for a mechanical brake should be supplied in a separate cable.

Power connections between the drive controller and motor should always be shielded or reinforced, and the shielding must have large-scale grounding at both ends! The use of EMC cable screw connections is recommended. These are not part of the scope of delivery.

Wiring suitable for EMC must be ensured.

3.5 Installing the INVEOR P

3.5.1 Mechanical installation




Fig.: 15 Applying thermal conductivity paste

Please proceed as follows to mechanically install the INVEOR P:

1. Clean the surface of the thermal sink on which the INVEOR P is to be fitted.
2. Use a spatula to apply the thermal conductivity paste (layer thickness 30 – 70 μ) on the underside of the INVEOR P.
3. Place the INVEOR P in the desired position.
4. Tightly connect the INVEOR P with the thermal sink.



IMPORTANT INFORMATION

During installation, ensure that the connection cable is not crushed!

3.5.2 Wiring diagram for INVEOR P size Alpha




Fig.: 16 Wiring diagram for size Alpha

Characters	Explanation
A1	Drive controller type: INVEOR P Alpha 2 (1AC 230 V)
G1	M6 grounding screw (connection for residual currents > 3.5 mA)
P1	RS485 internal programming interface (M12 plug) (optional)
P2	Internal potentiometer (optional)
Q1	Motor protection switch or load break switch (optional)
X1	Mains terminals
X411	Motor and PTC terminals
X5 – X6	Digital/analogue inputs and outputs


The drive controller is ready once a 230 V AC mains supply has been activated (on terminals L and N) or a 325 V DC mains supply has been activated (on terminals L and N).

3.5.3 Electrical installation for INVEOR P size Alpha



IMPORTANT INFORMATION

Compliance with the type of protection is the sole responsibility of the system integrator. If you have any questions, please ask your KOSTAL contact.



(also see 3.5.2 Wiring diagram INVEOR P size Alpha)


1. Attach the motor lines in the correct circuit to the motor plug (1).
2. If present, wire the connection cable of the motor PTC/Klixon to the T1 and T2 terminals.
 - * If the motor used does not have a motor PTC, you must connect the bridge included in the scope of delivery.

If the bridge is not connected, the red status LED lights up and the motor does not start.



IMPORTANT INFORMATION

Only motor PTCs corresponding to DIN 44081/44082 may be connected!



(also see [3.5.2](#) Wiring diagram INVEOR P size Alpha)




DANGER

Risk of death due to electrical shock!
Death or serious injury!
De-energise mains cable and secure it against being restarted.

3. Connect mains cables to mains plug (2) as follows:

230 V connection		
L	N	PE

Terminal no.	Designation	Assignment
1	L	Mains phase
2	N	Neutral wire
3	PE	Earth connection point



(also see 3.5.2 Wiring diagram INVEOR P size Alpha)


4. Connect control connections of application board as follows:

Control connection X5		
Terminal no.	Designation	Assignment
1	GND (ground)	Ground
2	En HW (enable)	Enable hardware
3	24 V Out	Int. power supply
4	24 V Out	Int. power supply
5	10 V Out	For ext. voltage divider
6	Dig. Out1	Fault message (parameter 4.150)
7	A GND (ground 10 V)	Ground
8	Dig. In 2	Free (not assigned)
9	A. In 1	Free (not assigned)
10	Dig. In 1	Target value enable (parameter 1.131)



IMPORTANT INFORMATION

If a control line is not attached, a bridge must be connected between "24 V Out" and "En. HW".



(also see 3.5.2 Wiring diagram INVEOR P size Alpha)

Relay X6 Designation	Assignment
COM	Centre contact relay
NO	Normally open contact relay
NC	Normally closed contact

For technical data on power connections, see chapter 3.3.2.

3.5.4 Electrical installation for INVEOR P size A-B



IMPORTANT INFORMATION

Compliance with the type of protection is the sole responsibility of the system integrator. If you have any questions, please ask your KOSTAL contact.




Fig.: 17 Electrical installation for INVEOR P size A-B



DANGER

Risk of death due to electrical shock!

Death or serious injury!

De-energise mains cable and secure it against being restarted.

1. Connect mains cables to mains terminal as follows:

230 V connection			
L1	N		PE
400 V connection			
L1	L2	L3	PE

Continues on next page

Continuation




Fig.: 18 Wiring for brake chopper connection cable



IMPORTANT INFORMATION

When connecting a brake resistor to an optional brake chopper (X3), cables with shielding and double insulation must be used!

2. Connect the cables of the brake resistor to the terminal (X3) as follows:

Connections for brake resistor (X3) (option)	
B+	Connection for brake resistor (+)
B -	Connection for brake resistor (-)

Continues on next page

Continuation




Fig.: 19 Wiring for motor PTC/Klixon connection cable

3. If present, wire the connection cable of the motor PTC/Klixon to the terminal (X11) as follows.

Connections for motor PTC / Klixon (X11)

1	(+)
2	(-)



IMPORTANT INFORMATION

If the motor is fitted with a temperature sensor, this is connected to the terminals (1) and (2). Remove the bridging contact inserted for delivery for this purpose.
When the bridge is in place, the temperature of the motor is not monitored!
Only motor PTCs corresponding to DIN 44081/44082 may be connected!

3.5.5 Electrical installation for INVEOR P size C-D



IMPORTANT INFORMATION

Compliance with the type of protection is the sole responsibility of the system integrator. If you have any questions, please ask your KOSTAL contact.




Fig.: 20 Electrical installation for INVEOR P size C-D



DANGER

Risk of death due to electrical shock!
Death or serious injury!
De-energise mains cable and secure it against being restarted.

1. Connect mains cables to mains terminal (X1) as follows:

400 V connection			
L1	L2	L3	PE

Continues on next page

Continuation




Fig.: 21 Wiring for brake chopper connection cable

**IMPORTANT INFORMATION**

When connecting a brake resistor to an optional brake chopper (X2/X3), cables with shielding and double insulation must be used!

2. Connect the cables of the brake resistor to the terminal (X2/X3) as follows:

Connections for brake resistor (X2/X3) (option)	
B+	Connection for brake resistor (+)
B -	Connection for brake resistor (-)

Continues on next page

Continuation




Fig.: 22 Wiring for brake chopper connection cable

3. If present, wire the connection cable of the motor PTC/Klixon to the terminal (X11) as follows.

Connections for motor PTC / Klixon (X11)

1	(+)
2	(-)



IMPORTANT INFORMATION

If the motor is fitted with a temperature sensor, this is connected to the terminals (1) and (2). Remove the bridging contact inserted for delivery for this purpose. When the bridge is in place, the temperature of the motor is not monitored! Only motor PTCs corresponding to DIN 44081/44082 may be connected!

3.5.6 Connection diagram for INVEOR P size A-D





Fig.: 23 Control connections for size A-D

Characters	Explanation
A1	Drive controller type: INVEOR Mx 4 (3 AC 400 V)
B1	Connection for external brake resistor (option)
G1	M6 grounding screw (connection for residual currents > 3.5 mA)
P1	RS485 programming interface (M12 plug)
P2	Internal potentiometer
Q1	Motor protection switch or load break switch (optional)
X1	Mains terminals
X5 – X7	Digital/analogue inputs and outputs

The drive controller is ready once a 400 V AC mains supply has been activated (on terminals L1 to L3) or a 565 V DC mains supply has been activated (on terminals L1 and L3).

The drive controller can also be started up by connecting an external 24 V voltage .



(also see 3.5.6 Wiring diagram INVEOR P for size A-D)




IMPORTANT INFORMATION

Danger of external signals being coupled in.
Use only shielded control line!

4. Connect the control cables according to the figure and/or table. Use shielded control cables.


Terminal no.	Designation	Assignment
13	A. Out 0 ... 20 mA	Actual frequency (parameter 4.100)
14	10 V Out	For ext. voltage divider
15	A. Out 0 ... 10 V	Actual frequency (parameter 4.100)
16	A GND (ground 10 V)	Ground
17	A. In 1	PID actual value (parameter 3.060)
18	A GND (Ground 10 V)	Ground
19	A. In 2	Free (not assigned)
20	A GND (ground 10 V)	Ground

Tab. 2



(also see 3.5.6 Wiring diagram INVEOR P for size A-D)

Terminal no.	Designation	Assignment
1	24 V In	Ext. power supply
2	GND (ground)	Ground
3	24 V Out	Int. power supply
4	GND (ground)	Ground
5	24 V Out	Int. power supply
6	Dig. In 1	Target value enable (parameter 1.131)
7	Dig. In 2	Free (not assigned)
8	Dig. In 3	Free (not assigned)
9	Dig. In 4	Error reset (parameter 1.180)
10	En HW (enable)	Enable hardware



(also see 3.5.6 Wiring diagram INVEOR P for size A-D)

Terminal no.	Designation	Assignment	
11	Dig. Out 1	Fault message (parameter 4.150)	
12	Dig. Out 2	Free (not assigned)	

X6 relay 1


Terminal no.	Designation	Assignment
1	COM	Centre contact relay 1
2	NO	Normally open relay 1
3	NC	Normally closed relay 1

Tab. 3



IMPORTANT INFORMATION

In the factory setting, relay 1 is programmed as “relay error” (parameter 4.190).



(also see 3.5.6 Wiring diagram INVEOR P for size A-D)

X7 relay

Terminal no.	Designation	Assignment
1	COM	Centre contact relay 2
2	NO	Normally open relay 2
3	NC	Normally closed relay 2

Tab. 4



INFORMATION

In the factory setting, “no function” is assigned to relay 2 (parameter 4.210).

Control connections of the basic application board




Fig.: 24 Control connections of the basic application board (configuration feature AP03)

Terminal no.	Designation	Assignment
1	Dig. In 1	Target value enable (parameter 1.131)
2	A. In 1	Free (not assigned)
3	Dig. In 2	Free (not assigned)
4	A GND (ground 10 V)	Ground
5	Dig. Out	Fault message (parameter 4.150)
6	10 V Out	For ext. voltage divider
7	24 V Out	Int. power supply
8	24 V Out	Int. power supply
9	En HW (enable)	Enable hardware
10	GND (ground)	Ground

4. Commissioning

4.1	Commissioning of INVEOR P size Alpha	73
4.2	Commissioning INVEOR P size A-D	73

4.1 Commissioning of INVEOR P size Alpha

You will find the "Commissioning" chapter for the INVEOR P (size Alpha) in the detailed operating manual for the INVEOR Alpha.

Please download the complete operating manual for the INVEOR Alpha from the download area of our website under the following link:

<https://www.kostal-industrie-elektrik.com/downloads>

4.2 Commissioning INVEOR P size A-D

You will find the "Commissioning" chapter for the INVEOR P (size A-D) in the detailed operating manual for the INVEOR.

Please download the complete operating manual for the INVEOR from the download area of our website under the following link:

<https://www.kostal-industrie-elektrik.com/downloads>

5. Parameter

5.1	Parameters for INVEOR P size Alpha	74
5.2	Parameters for INVEOR P size A-D	74

5.1 Parameters for INVEOR P size Alpha

You will find the "Parameters" chapter for the INVEOR P (size Alpha) in the detailed operating manual for the INVEOR Alpha.

Please download the complete operating manual for the INVEOR Alpha from the download area of our website under the following link:

<https://www.kostal-industrie-elektrik.com/downloads>

5.2 Parameters for INVEOR P size A-D

You will find the "Parameters" chapter for the INVEOR P (size A-D) in the detailed operating manual for the INVEOR.

Please download the complete operating manual for the INVEOR from the download area of our website under the following link:

<https://www.kostal-industrie-elektrik.com/downloads>

6. Error detection and troubleshooting

6.1	Error detection and troubleshooting for INVEOR P size Alpha	75
6.2	Error detection and troubleshooting for INVEOR P size A-D	75

6.1 Error detection and troubleshooting for INVEOR P size Alpha

You will find the "Error detection and troubleshooting" chapter for the INVEOR P (size Alpha) in the detailed operating manual for the INVEOR Alpha.

Please download the complete operating manual for the INVEOR Alpha from the download area of our website under the following link:

<https://www.kostal-industrie-elektrik.com/downloads>

6.2 Error detection and troubleshooting for INVEOR P size A-D

You will find the "Error detection and troubleshooting" chapter for the INVEOR P (size A-D) in the detailed operating manual for the INVEOR.

Please download the complete operating manual for the INVEOR from the download area of our website under the following link:

<https://www.kostal-industrie-elektrik.com/downloads>

7. Disassembly and disposal

7.1	Drive controller disassembly	76
7.2	Information on correct disposal.....	76

This chapter contains the following:

- a description of how to disassemble the drive controller
- Information on correct disposal

7.1 Drive controller disassembly

DANGER!



Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being restarted.



Danger due to electrical shock and discharge.

Wait two minutes (discharge time of the capacitors) after shut-down

DANGER!



Risk of death due to electrical shock!

Death or serious injury!

De-energise drive controller and secure it against being switched back on before removing housing parts which provide protection against contact with live parts.

7.2 Information on correct disposal

Dispose of drive controller, packaging and replaced parts in accordance with the regulations of the country in which the drive controller has been installed.

The drive controller may not be disposed of with household waste.


+

8. Technical data

8.1	General data.....	78
8.1.1	General technical data for 230 V/400 V devices.....	78

8.1 General data

8.1.1 General technical data for 230 V/400 V devices

Size	230 V		400 V				
	Pα	PA (1 AC)	PA (3 AC)	PB (3 AC)	PC (3 AC)	PD (3 AC)	PD (3 AC)
Recommended motor rating (4-pole asynchr. motor)	0.75	1.1	1.5	4.0	7.5	15.0	22.0
Ambient temperature [°C]	- 10 °C (non condensing) to + 40 °C (50 °C with derating) ¹		- 25 °C (non condensing) to + 50 °C (without derating)			- 25 °C (non condensing) to + 40 °C (without derating)	
Mains voltage [V]	1 x 100 VAC – 15 % ...230 VAC + 10 %		3 x 200 VAC – 10 %...480 VAC + 10 %				
Mains frequency [Hz]	50 Hz / 60 Hz ± 6 %						
Mains configurations	TN / TT / IT (options)		TN / TT				
Mains current [A]	7.3	9.2	3.3	7.9	14.8	28.2	39.8
Nominal current output eff. [I _N at 8 kHz / 230 V]	3.3	5.2	-	-	-	-	-
Nominal current output eff. [I _N at 8 kHz / 400 V]	-		4.0	9.5	17.8	34.0	48.0
Min. brake resistance [Ω]	-	50	100	50	50	30	
Maximum overload	150 % of nominal current for 60 sec						130 % of nominal current for 60 sec
Switching frequency	4 kHz, 8 kHz, 16 kHz, (factory setting 8 kHz)						
Rotating field frequency	0 Hz – 400 Hz						
Protective functions	Overvoltage and undervoltage, I ² t restriction, short circuit, motor- drive controller temperature, anti-tilt protection, stall protection						
Process control	Freely configurable PID controller						
Dimensions [L x W x H] mm	210x120x71	261.5x150x82.9	261.5x150x82.9	300x185x83.3	330x220x91	343x270x113	
Weight including cooling plate [kg]	1.6	2.2	2.2	2.9	4.2	6.5	
Protection type [IPxy]	IP 00 (type of protection is determined by the final application) ¹						
EMC	prepared for satisfying DIN EN 61800-3, class C2	prepared for satisfying DIN EN 61800-3, class C1	prepared for satisfying DIN EN 61800-3, class C2				
Certificates and conformity							

Tab. 5: Technical data for 230 V and 400 V INVEOR P devices
(subject to technical changes)

* The recommended motor rating is stated for single-phase and three-phase devices based on a grid voltage of 230 VAC and 400 VAC.

Subject to technical change.

INVEOR P size Alpha	
Designation	Function
Digital inputs 1 – 2	<ul style="list-style-type: none"> - Switching level low < 5 V / high > 15 V - I_{max} (at 24 V) = 3 mA - R_{in} = 8.6 kOhm
Analogue inputs 1	<ul style="list-style-type: none"> - In +/- 10 V or 0 – 20 mA - In 2 – 10 V or 4 – 20 mA - 10-bit resolution - Tolerance +/- 2 % <p>Voltage input:</p> <ul style="list-style-type: none"> - R_{in} = 10 kOhm <p>Current input:</p> <ul style="list-style-type: none"> - Working resistance = 500 Ohm
Digital outputs 1	<ul style="list-style-type: none"> - Short-circuit proof - I_{max} = 20 mA
Relay 1	<p>1 changeover contact (NO/NC)</p> <p>Maximum switching power *</p> <ul style="list-style-type: none"> - at ohmic load (cos φ = 1): 5 A at 1 AC 230 V or = 30 V - at inductive load (cos φ = 0.4 and L/R = 7 ms): 2 A at 1 AC 230 V or = 30 V <p>Maximum reaction time: 7 ms ± 0.5 ms</p> <p>Electric life: 100 000 switching cycles</p>
Power supply 24 V	<ul style="list-style-type: none"> - Auxiliary voltage U = 24 V DC - Short-circuit proof - I_{max} = 100 mA (depending on device configuration) - external feeding of 24 V possible
Power supply 10 V	<ul style="list-style-type: none"> - Auxiliary voltage U = 10 V DC - Short-circuit proof - I_{max} = 30 mA

Tab. 6: Specification of interfaces (size Alpha)

* in accordance with UL-61800-5-1, the maximum allowed is 2 A!

INVEOR P size A-D Designation	Function
Digital inputs 1 – 4	<ul style="list-style-type: none"> - Switching level low < 2 V / high > 18 V - I_{max} (at 24 V) = 3 mA - R_{in} = 8.6 kOhm
Hardware approval for input	<ul style="list-style-type: none"> - Switching level low < 3 V / high > 18 V I_{max} (at 24 V) = 8 mA
Analogue inputs 1, 2	<ul style="list-style-type: none"> - I_n +/- 10 V or 0 – 20 mA - I_n 2 – 10 V or 4 – 20 mA - 10-bit resolution - Tolerance +/- 2 % <p>Voltage input:</p> <ul style="list-style-type: none"> - R_{in} = 10 kOhm <p>Current input:</p> <ul style="list-style-type: none"> - Working resistance = 500 Ohm
Digital outputs 1, 2	<ul style="list-style-type: none"> - Short-circuit proof - I_{max} = 20 mA
Relays 1, 2	<p>1 changeover contact (NO/NC)</p> <p>Maximum switching power *</p> <ul style="list-style-type: none"> - at ohmic load (cos φ = 1): 5 A at 1 AC 230 V or = 30 V - at inductive load (cos φ = 0.4 and L/R = 7 ms): 2 A at 1 AC 230 V or = 30 V <p>Maximum reaction time: 7 ms ± 0.5 ms</p> <p>Electric life: 100 000 switching cycles</p>
Analogue output 1 (current)	<ul style="list-style-type: none"> - Short-circuit proof - I_{out} = 0.. 20 mA - Working resistance = 500 Ohm - Tolerance +/- 2 %
Analogue output 1 (voltage)	<ul style="list-style-type: none"> - Short-circuit proof - U_{out} = 0.. 10 V - I_{max} = 10 mA - Tolerance +/- 2 %
Power supply 24 V	<ul style="list-style-type: none"> - Auxiliary voltage U = 24 V DC - SELV - Short-circuit proof - I_{max} = 100 mA (depending on device configuration) - external feeding of 24 V possible
Power supply 10 V	<ul style="list-style-type: none"> - Auxiliary voltage U = 10 V DC - Short-circuit proof - I_{max} = 30 mA

Tab. 7: Specification of interfaces (size A-D)

* in terms of the UL 508C standard, the maximum allowed is 2 A!

9. Optional accessories

9.1	MMI handheld controller including a 3 m RJ9 connection cable with M12 plug	83
9.2	MMI*/connecting cable PIN assignment.....	84
9.3	PC communication cable USB on M12/RS485 plug (converter integrated).....	85
9.4	Adapter cable for INVEOR P size Alpha	86
9.5	Internal potentiometer	86
9.6	MMI M12 plug (JST plug)	87
9.7	CANopen connection cable.....	88
9.8	PROFIBUS connection cable.....	89
9.9	Ethercat/PROFINET/Sercos III connection cable	90
9.10	Thermal conductivity paste.....	91

This chapter contains brief descriptions of the following optional accessories:

- MMI handheld controller
- MMI/connecting cable PIN assignment
- PC communication cable USB on M12 plug
- INVEOR P Alpha adapter cable
- Internal potentiometer
- MMI M12 plug (JST plug)
- CANopen connection cable
- Profibus connection cable
- Thermal conductivity paste

9.1 MMI handheld controller including a 3 m RJ9 connection cable with M12 plug




Fig.: 25 MMI handheld controller



IMPORTANT INFORMATION

The MMI handheld controller (part. no. 10004768) may only ever be used with an INVEOR!

The MMI handheld controller is connected to the M12 interface (option) of the INVEOR P. With the INVEOR P size Alpha, the MMI handheld controller can also be connected to the internal jack plug. The INVEOR Alpha adapter cable (art. no. 10118219) is needed for this.



Fig.: 26 INVEOR P Alpha adapter cable

The MMI handheld controller allows the user to write (program) and/or to visualise all the parameters of the INVEOR P. Complete commissioning is possible as an alternative to the free INVEORpc software. External signals are not needed.

9.2 MMI*/connecting cable PIN assignment




Fig.: 27 MMI connecting cable, can be ordered along with handheld controller, order number 10004768




Fig.: 28 M12 plug PIN assignment

Description: Round plug connector (plug)
4-pin M12 A-coded.

M12 plug assignment	Signal
1	24 V
2	RS485 - A
3	GND
4	RS485 - B




Fig.: 29 RJ9 plug connector

Description: RJ9 plug connector

Pin	Signal
1	yellow
2	green
3	red
4	brown
Attention: The colours may vary!	

* Man-machine interface

9.3 PC communication cable USB on M12/RS485 plug (converter integrated)



Fig.: 30 PC communication cable USB on M12 plug

As an alternative to the MMI handheld controller, an INVEOR P can also be put into operation using the PC communication cable (art no. 10023950) and the INVEORpc software. The "INVEOR Alpha adapter cable" (art. no. 10118219) is also needed for this. As an alternative to using the "INVEOR Alpha adapter cable", the PC communication cable can be connected via the M12 socket (art. no. 10118216) (JST plug).

The INVEORpc software is available free of charge from the KOSTAL homepage at <https://www.kostal-industrie-elektrik.com/downloads>

9.4 Adapter cable for INVEOR P size Alpha




Fig.: 31 INVEOR Alpha adapter cable

The "INVEOR P Alpha adapter cable" is needed to connect the MMI handheld controller or PC communication cable with the INVEOR P Alpha.



IMPORTANT INFORMATION

The "INVEOR P Alpha adapter cable" (art. no. 10118219) may only ever be used with an INVEOR Alpha!

9.5 Internal potentiometer




Fig.: 32 Internal potentiometer

The internal potentiometer (art. no. 10118232) is used to specify the nominal speed in an infinitely variable manner.

9.6 MMI M12 plug (JST plug)




Fig.: 33 MMI M12 plug (JST plug)

Round plug connector (socket) 4-pin M12 A-coded.

The MMI M12 connection cable (art. no.: 10118216) can be used to permanently connect the drive controller with the MMI or PC.



IMPORTANT INFORMATION

Note that the MMI/PC interface is not intended for connecting several control devices!

M12 plug assignment	Signal
1	24 V
2	RS485 - A

M12 plug assignment	Signal
3	GND
4	RS485 - B

9.7 CANopen connection cable




Fig.: 34 CANopen connection cable

The connection cable (art. no.: 10118224) can be used to connect the drive controller to a CANopen bus system.

CANopen connection cable pin assignment			
JST plug pin assignment	Line colour	Signal	M12 plug assignment
1	black	CAN_L	5
2	white	CAN_H	4
3	blue	GND	3
		Not used	1
		Not used	2

9.8 PROFIBUS connection cable




Fig.: 35 PROFIBUS connection cable

The connection cable (art. no.: 10056418) can be used to connect the drive controller to a PROFIBUS bus system.

PROFIBUS connection cable pin assignment			
JST plug pin assignment	Line colour	Signal	M12 plug assignment
1			
2	brown	VP	1
3			
4			
5	red	RXD / TXD-P	4
6	green	RXD / TXD-N	2
7			
8			3
9	blue	DGND	
			5

9.9 Ethercat/PROFINET/Sercos III connection cable




Fig.: 36 EtherCAT/PROFINET/Sercos III connection cable

The connection cable (art. no.: 10085888) can be used to connect the drive controller to an EtherCAT/PROFINET/Sercos III bus system.

Pin assignment for EtherCAT/PROFINET/Sercos III		
Pin assignment RJ 45 plug	Signal	Assignment for M12 plug
1	Tx +	1
2	Tx -	3
3	Rx +	2
4		
5		
6	Rx -	4
7		
8		

9.10 Thermal conductivity paste




Fig.: 37 Thermal conductivity paste spraying device

The thermal conductivity paste (art. no: 10139778) improves heat transfer between the cooling plate and thermal sink.

For the correct way to apply this paste, please consult chapter [3.5.1 Mechanical installation](#).

10. Approvals, standards and guidelines

10.1	EMC limit classes.....	93
10.2	Classification acc. to IEC/EN 61800-3.....	94
10.3	Standards and guidelines.....	94
10.4	UL approval.....	95
10.4.1	UL Specification (English version).....	95
10.4.2	Homologation CL (Version en française).....	98

This chapter contains information about electromagnetic compatibility (EMC), and applicable guidelines, norms and standards.

Because the INVEOR P device is based on the housed INVEOR M device, the INVEOR P is provided with all filter measures.

The system integrator therefore only has to remeasure the integrated electronics together with his or her specific housing with regard to the EMC stated in DIN

[EN 61800-3:2004/A1:2012](#).

Requirements of a housing with proper EMC:

- closed, earthed metallic surface
- EMC screw connections

For binding information about the relevant drive controller approvals, please refer to the type plate for the entire device!

10.1 EMC limit classes

Please note that EMC limit classes are only reached if the standard switching frequency of 8 kHz is complied with.

Depending on the installation material used and/or extreme ambient conditions, it might be necessary to use additional sheath wave filters (ferrite rings). If mounting on a wall, the shielded motor cable must not exceed a maximum length of 3 m!

Wiring suitable for EMC also requires that EMC screw connections be used on both sides (drive controller and motor).



IMPORTANT INFORMATION

In a residential environment, this product can cause high-frequency disturbances that may require interference suppression measures.

10.2 Classification acc. to IEC/EN 61800-3

The generic standard defines test procedures and severity levels for every environment in the drive controller category; these have to be complied with.

Definition of environment

First environment (residential, commercial and industrial area):

All “areas” that are directly supplied by a public low-voltage connection, such as:

residential area, e.g. houses, apartments etc.

retail area, e.g. shops, supermarkets

public institutions, e.g. theatres, stations

outside areas, e.g. petrol stations and parking areas

light industry, e.g. workshops, laboratories, small businesses

Second environment (industry):

Industrial environments with their own supply network that is separated from the public low-voltage supply by a transformer.

10.3 Standards and guidelines

The following specifically apply:

Directive on Electromagnetic Compatibility

(Directive 2014/30/EU Standard: EN 61800-3 2004/A1:2012).

Low Voltage Directive

(Directive 2014/35/EU Standard EN 61800-5-1:2007)

RoHS Directive

Directive 2011/65/EU Standard EN 50581 :2012

10.4 UL approval

10.4.1 UL Specification (English version)

CONDITIONS OF ACCEPTABILITY:

Use - For use only in complete equipment where the acceptability of the combination is determined by Underwriters Laboratories Inc.

1. INV P Alpha:

These cold-plate drives are designed for installation on an external heatsink in the end-use. Unless operated other than as specified in item 2 of the Conditions of Acceptability below, temperature test shall be repeated in the end-use.

INV PA 2 / INV PA 4 / INV PB 4 / INV PC 4 / INV PD 4:

These drives are incomplete in construction and have to be attached to an external heatsink in the end-use. Unless operated with the heatsink as noted in item 2 of the conditions of acceptability below, temperature test shall be conducted in the end-use.

2. INV P Alpha:

Temperature test on these drives was conducted without any external heatsink (only with cold-plate being integral part of the drive) at rated load and maximum surrounding air temperature of 50 °C.

Temperature test was conducted at rated load and maximum surrounding air temperature with drive installed on aluminum heatsink, overall dimensions, shape and number of ribs as outlined below:

INV P Alpha / INV PA 2 / INV PA 4 / INV PB 4 / INV PC 4:

Temperature test was conducted with drive installed on aluminum heatsink, overall dimensions and ribs shape as outlined below:

Drive series	Overall heatsink dimensions (W x H x L) in millimeters	Illustration	Max. surrounding air temperature
INV P Alpha	120 x 27 x 210	ILL. 1	60 °C
INV PA 2*	150 x 27 x 210	ILL. 1	50 °C
INV PA 4**	150 x 27 x 210	ILL. 1	65 °C
INV PB 4**	200 x 40 x 250	ILL. 2	60 °C
INV PC 4**	216 x 83 x 300	ILL. 3	65 °C

*2 = IV 02

**4 = IV 01

INV PD 4:

Temperature test was not conducted on models INV PD 4. Suitability of drive - heatsink combination shall be determined by subjecting to temperature test in the end-use.

3. INV PA 2 / INV PA 4 / INV PB 4 / INV PC 4 / INV PD 4:

Suitability of grounding for the combination of drive and heatsink needs to be verified in accordance with the end-use standard.

Required Markings

Mechanical considerations: mounting drawing; handling and mounting instructions **see chapter 3.4 in the operating manual.**

Marking for proper connection; range of values or a nominal value of tightening torque in pound-inches to be applied to the clamping screws of all terminal connectors for field wiring **see chapter 3.4 in the operating manual.**

CAUTION: "Use 75 °C wires only"

CAUTION: "Use Copper Conductors Only"

CAUTION: "Suitable For Use On A Circuit Capable Of Delivering Not More Than 5000 A rms Symmetrical Amperes, 240 Volts Maximum" and "When Protected by RK5 Class Fuses rated 15 A"

Indication of motor overload protection level in percent of full-load current. **Internal Overload Protection Operates within 60 seconds when reaching 150 % of the Motor Full Load Current.**

CAUTION: "Motor overtemperature sensing is not provided by the drive".

CAUTION: "Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the Manufacturer Instructions, National Electrical Code and any additional local codes."

CAUTION: For used in Canada: "TRANSIENT SURGE SUPPRESSION SHALL BE INSTALLED ON THE LINE SIDE OF THIS EQUIPMENT AND SHALL BE RATED 240 V (PHASE TO GROUND), SUITABLE FOR OVERVOLTAGE CATEGORY III, AND SHALL PROVIDE PROTECTION FOR A RATED IMPULSE WITHSTAD VOLTAGE PEAK OF 2.5 kV".

CAUTION: "For use in Pollution Degree 2 Environment only".

INV PA 2:

"Internal Overload Protection Operates within 60 seconds when reaching 150 % of the Motor Full Load Current".

CAUTION: "Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes."

CAUTION: "Suitable For Use On A Circuit Capable Of Delivering Not More Than 5 kA rms Symmetrical Amperes, 240 Volts Maximum when Protected by Fuses".

All wiring terminals marked to indicate proper connections for the power supply, load and control circuitry **see chapter 3.4 in the operating manual.**

CAUTION: Use 75 °C copper wires only.

CAUTION: "Motor overtemperature sensing is not provided by the drive".

CAUTION: "For use in Pollution Degree 2 only."

Illustrations




Fig.: 38 ILL. 1




Fig.: 39 ILL. 2




Fig.: 40 ILL. 3

10.4.2 Homologation CL (Version en française)

CONDITIONS D'ACCEPTABILITÉ :

Usage : usage uniquement réservé aux équipements complets dont l'acceptabilité de la combinaison est déterminée par la société Underwriters Laboratories Inc.

1. INV P Alpha :

Ces commandes à plaques de refroidissement sont destinées à être installées sur un dissipateur thermique externe en utilisation finale. Sauf en cas d'exploitation autre que celle indiquée à l'élément 2 des conditions d'acceptabilité ci-dessous, le test de température doit être répété en utilisation finale.

INV PA 2 / INV PA 4 / INV PB 4 / INV PC 4 / INV PD 4 :

Ces commandes ne sont pas complètement finies et doivent être fixées à un dissipateur thermique externe en utilisation finale. Sauf en cas d'exploitation avec le dissipateur thermique comme cela est précisé à l'élément 2 des conditions d'acceptabilité ci-dessous, le test de température doit être effectué en utilisation finale.

2. INV P Alpha :

Le test de température sur ces commandes a été effectué sans dissipateur thermique externe (uniquement avec une plaque de refroidissement faisant partie intégrante de la commande) à la charge nominale et à une température ambiante maximale de 50 °C.

Le test de température a été effectué à charge nominale et à la température ambiante maximale alors que la commande était installée sur un dissipateur thermique en aluminium. Les dimensions générales, la forme et le nombre de nervures correspondaient à ceux indiqués ci-dessous :

INV P Alpha / INV PA 2 / INV PA 4 / INV PB 4 / INV PC 4:

Le test de température a été effectué alors que la commande était installée sur un dissipateur thermique en aluminium. Les dimensions générales et la forme des nervures correspondaient à celles indiquées ci-dessous :

Série de commandes	Dimensions générales du dissipateur thermique (largeur x hauteur x longueur) en millimètres	Illustration	Température maxi. de l'air ambiant
INV P Alpha	120 x 27 x 210	ILL. 1	60 °C
INV PA 2	150 x 27 x 210	ILL. 1	50 °C
INV PA 4	150 x 27 x 210	ILL. 1	65 °C
INV PB 4	200 x 40 x 250	ILL. 2	60 °C
INV PC 4	216 x 83 x 300	ILL. 3	65 °C

2 = IV 02

4 = IV 01

INV PD 4 :

Le test de température n'a pas été effectué sur les modèles INV PD 4. L'adéquation de l'association commande - dissipateur thermique sera déterminée par la réalisation du test de température en utilisation finale.

3. INV PA 2 / INV PA 4 / INV PB 4 / INV PC 4 / INV PD 4:

Suitability of grounding for the combination of drive and heatsink needs to be verified in accordance with the end-use standard.

Mentions obligatoires

Considérations mécaniques : plan de montage ; instructions de manipulation et montage, **voir chapitre 3.4 du manuel d'exploitation.**

Mention relative au bon raccordement ; plage de valeurs ou valeur nominale du couple de serrage en livres-pouces à appliquer aux vis de serrage de tous les connecteurs de borne pour le câblage de champ, **voir chapitre 3.4 du manuel d'exploitation.**

AVERTISSEMENT : « Utiliser uniquement des câbles de 75 °C »

AVERTISSEMENT : « Utiliser uniquement des conducteurs en cuivre »

AVERTISSEMENT : « Convient à une utilisation sur un circuit capable de fournir un courant maximal de 5 000 ampères symétriques (A rms) et une tension maximale de 240 volts » et « en cas de protection par des fusibles de 15 A de classe RK5 »

Indication du niveau de protection contre la surcharge du moteur en pourcentage du courant nominal. **La protection interne contre les surcharges se déclenche dans un délai de 60 secondes lorsque la surcharge atteint 150 % du courant nominal du moteur.**

AVERTISSEMENT : « La commande ne détecte pas la surchauffe du moteur ».

AVERTISSEMENT : « Le système de protection intégrale contre les courts-circuits des relais statiques ne protège pas les circuits de dérivation. La protection des circuits de dérivation doit être assurée conformément aux instructions du fabricant, au Code national de l'électricité et à tous les autres codes locaux. »

AVERTISSEMENT : Pour utilisation au Canada : « L'ÉCRÉTAGE DE TENSION TRANSITOIRE DOIT ÊTRE INSTALLÉ DU CÔTÉ LIGNE DE CET ÉQUIPEMENT ET DOÎT ÊTRE CONÇU POUR 240 V (PHASE - TERRE), ÊTRE CONFORME À LA CATÉGORIE DE SURTENSION III ET FOURNIR UNE PROTECTION CONTRE UNE TENSION ASSIGNÉE DE TENUE AUX CHOCS DE 2,5 kV ».

AVERTISSEMENT : « Uniquement pour utilisation dans un environnement de degré de pollution 2 ».

INV PA 2 :

« La protection interne contre les surcharges se déclenche dans un délai de 60 secondes lorsque la surcharge atteint 150 % du courant nominal du moteur ».

AVERTISSEMENT : « Le système de protection intégrale contre les courts-circuits des relais statiques ne protège pas les circuits de dérivation. La protection des circuits de dérivation doit être assurée conformément au Code national de l'électricité et à tous les autres codes locaux. »

AVERTISSEMENT : « Convient à une utilisation sur un circuit capable de fournir un courant maximal de 5 000 ampères symétriques (kA rms) et une tension maximale de 240 volts en cas de protection par des fusibles ».

Toutes les bornes marquées pour indiquer les raccordements adéquats pour le circuit de commande, de charge et d'alimentation électrique, **voir chapitre 3.4 du manuel d'exploitation**.

AVERTISSEMENT : Utiliser uniquement des câbles en cuivre de 75 °C.

AVERTISSEMENT : « La commande ne détecte pas la surchauffe du moteur ».

AVERTISSEMENT : « Uniquement pour utilisation dans un environnement de degré de pollution 2 ».

Illustrations




Fig. : 38 ILL. 1




Fig. : 39 FIG. 2




Fig.: 40

11. Index

A

Ambient conditions 36

Analogue input 66

Analogue output 66

C

Commissioning 71

D

Digital input 57, 67, 70

Digital output 57, 68, 70

E

EMC limit classes 90

EMC screw connections 91

EMC standard 90

Error detection 73

EU Declaration of Conformity 15

F

FI protection switch 24

Frequency 66

G

General technical data for 230 V/400 V devices 76

I

Information about commissioning.....	23
Installation altitude	36
Instructions concerning operation.....	25

L

Label on the drive controller.....	12
------------------------------------	----

M

Mains activations	25
MMI.....	81
Model description size Alpha, size A - D.....	29

O

Optional accessories.....	79
---------------------------	----

P

Parameter.....	72
Parameterisation.....	8
PC cable	83
Project planning information for housing design	16
Proper use.....	13

R

Repairs.....	27
--------------	----

S

Safety instructions.....	21, 34
Standards.....	92

T

Technical data 75

Thermal conductivity paste 53, 89

Transport & storage 23

U

UL93



KOSTAL Industrie Elektrik GmbH
Lange Eck 11
58099 Hagen
Deutschland

Service-Hotline: +49 2331 8040-848
Telefon: +49 2331 8040-800
Telefax: +49 2331 8040-602

www.kostal-industrie-elektrik.com