




front view  
scale: 1:1

Left view  
Scale: 1:1


Rear view  
Scale: 1:1



Schraube M6x14,  
Federring



Isometric view  
Scale: 1:1



Schraube M6x20,  
Federring

### Adapterplatte

Schraube M6x20,  
Federring

Isometric view  
Scale: 1:1

**Hinweis:**  
**Es gilt die Installationsanleitung**  
**"Betriebsanleitung INVEOR"**  
 THE INSTALLATION INSTRUCTION "OPERATING MANUAL INVEOR"  
 IS THE DOMINATION DOCUMENT

<b>Nenngröße</b>	<b>Anzugsdrehmomente</b>
Schrauben M6	8,5 Nm
Schrauben M8	25 Nm

[illegible]